

## Reece Safety Products Ltd

Unit B9, Lowfields Close, Lowfields Business Park, Elland, West Yorkshire HX5 9DX

Tel: 01422 310456 Fax: 01422 311070 Email sales@reecesafety.co.uk www.reecesafety.co.uk



### Product Information and Assembly Instructions - Light Switch Lockout R496B

#### Changing Dual Purpose Switch Slides

Dual Purpose Slides have the words "TOGGLE" and "ROCKER" molded on opposite sides.



When "TOGGLE" appears through the cover, the lockout device is set for a Toggle style switch.



When "ROCKER" appears through the cover, the lockout device is set for a Rocker or Paddle style switch.




To change between "TOGGLE" and "ROCKER", apply firm pressure to remove the Dual Purpose Slide from Base. Flip the Slide over and snap back into place. Repeat on second Slide.

#### Parts Identification



#### Installation On Switch



Move switch to either Off or On position for necessary maintenance. Close cover, apply safety padlock.



#### 496B

Universal Toggle/Rocker Wall Switch Lockout Device  
Dispositif universel de verrouillage d'interrupteur mural à bascule ou à palette  
Dispositivo de bloqueo para interruptor universal basculante/conmutador de pared

Made in China - Fabriqué en Chine - Hecho en China  
©2014 Master Lock Company

56078

